

# STV Eliminator

## Supplementary Manual

### Suzuki GSX-S1000F ABS TC 2015-2016 (STVE-06)

Secure the bike on a stand.



Remove the seats.

Remove the side fairings.

Remove the plastic covers from the fuel tank.

Remove the fuel tank and the airbox.



Locate the throttle body assembly under the airbox tank.

Find the two connectors of the actuator motor and the STPS (secondary throttle position sensor) on the throttle body assembly.



# STV Eliminator

## Supplementary Manual



### Suzuki GSX-S1000F ABS TC 2015-2016 (STVE-06)

Remove the butterfly valve flaps/throttle plates.

Plug the STVE module into the 4-pole Black wiring harness connector.

Plug the STVE module into the 3-pole Black wiring harness connector.

Secure the unit properly.

