

# STV Eliminator

## Supplementary Manual

### Suzuki SFV650 2009-2015 (STVE-06)

Secure the bike on a stand.




Remove the seat and the side covers.

Remove the fuel tank and the airbox.



Locate the throttle body assembly under the airbox.

Find the two connectors of the actuator motor and the STPS (secondary throttle position sensor) on the throttle body assembly.



# STV Eliminator

## Supplementary Manual



### Suzuki SFV650 2009-2015 (STVE-06)

Remove the butterfly valve flaps/throttle plates.

Plug the STVE module into the 4-pole Black wiring harness connector.

Plug the STVE module into the 3-pole Grey wiring harness connector.



Typical position for the STV Eliminator.

Secure the unit properly.

